

Table of Contents

1	SCOPE AND CLASSIFICATION	1	3.3.8	JBA8: Excess Potting Compound in Junction Box for Bus Ribbons	29
2	APPLICABLE DOCUMENTS	1	3.3.9	JBA9: Insufficient Solder (only for specific junction boxes)	30
2.1	IPC	1	3.3.10	JBA10: Excess Solder (only for specific junction boxes)	30
2.2	British Standards Institution (BSI)	1	3.3.11	JBA11: Junction Box Lid Closure	31
2.3	Underwriters Laboratories (UL)	1	3.3.12	JBA12: Bus Bar Connections	32
2.4	IEC	1	3.3.13	JBA13: Bus Bar Contact Weld to Junction Box (only for specific junction boxes with plastic housing)	35
2.5	ISO	1	3.3.14	JBA14: Damaged Outer Plastic Case of Junction Box	35
3	REQUIREMENTS	2	3.3.15	JBA15: Damaged Plastic Housing for Junction Box Cable Terminations	36
3.1	Frame	2	3.3.16	JBA16: Contaminated Terminals or Contacts	37
3.1.1	F1: Frame Scratches and General Frame Condition (Incoming Frame)	2	3.3.17	JBA17: Junction Box Assembly Seating Plane	37
3.1.2	F2: Frame Scratches (Finished Frame)	3	3.3.18	JBA18: Junction Box Wiring/Cabling	38
3.1.3	F3: Straightness (Incoming Frame)	3	3.3.19	JBA19: Junction Box Connectors	38
3.1.4	F4: Frame Straightness (Finished Frame)	4	3.4	Mounting Hardware	39
3.1.5	F5: Frame Color and Surface Finish	4	3.4.1	MH1: Mounting Holes and Grounding Holes	39
3.1.6	F6: Frame Squareness	7	3.4.2	MH2: Mounting Hardware Type	40
3.2	Frame Assembly	7	3.5	Serial Number and Identification Label	40
3.2.1	FRA1: Frame Assembly-Alignment/Gaps (At corners)	7	3.5.1	L1: Label Content	40
3.2.2	FRA2: Frame Assembly Excessive Sealant	9	3.5.2	L2: Label Location and Alignment	41
3.2.3	FRA3: Frame Assembly Insufficient Sealant	11	3.5.3	L3: Label Legibility	42
3.2.4	FRA4: Frame Assembly Missing Screw	12	3.5.4	L4: Label Serial Number and Date Code of Manufacture	42
3.2.5	FRA5: Frame Assembly Screw Installation	14	3.5.5	L5: Marking Type	42
3.2.6	FRA6: Frame Assembly Corner Edge Alignment	16	3.6	Final Module Assembly	43
3.2.7	FRA7: Frame Assembly Tape	18	3.6.1	PFA1: Final Assembly-External Contamination (e.g., stains, fingerprints, oils, foreign matter)	43
3.3	Junction Box Assembly	19	3.6.2	PFA2: Label Alignment	44
3.3.1	JBA1: Junction Box Assembly Alignment	19	3.6.3	PFA3: Serial Number Scannable and Readable	44
3.3.2	JBA2 Junction Box Requirements for Ribbon Connections in a Mechanical Clamping Configuration	21	3.6.4	PFA4: Missing Component (e.g., lid on junction box, label, screw, etc.)	44
3.3.3	JBA3: Insufficient Sealant around Junction Box	22	3.6.5	PFA5: Final Assembly – Junction Box Cable Tying	45
3.3.4	JBA4: Excess Sealant around Junction Box	24	3.6.6	PFA6: Backsheet separation	45
3.3.5	JBA5: Insufficient Sealant in Junction Box for Bus Ribbons	25	3.6.7	PFA7: Broken or Cracked Glass or Glass Abrasion	46
3.3.6	JBA6: Insufficient Potting Compound in Junction Box for Bus Ribbons	26	3.7	Electrical Test after Final Visual Inspection	47
3.3.7	JBA7: Excess Sealant in Junction Box for Bus Ribbons	28			

3.8	Electroluminescence Testing (Final Module)	47
3.8.1	EL1: Electroluminescence Testing	47
4	BEST PRACTICES IN MANUFACTURING AND EXAMPLES OF SHIPMENT OF MODULES	48
4.1	Frame Squareness Best Practice	48
4.2	Lid Closure Best Practice	48
4.3	Junction Box Assembly Seating Plane Best Practice	49
4.4	Label Alignment Best Practice	49
4.5	PV Module Packaging	50

Figures

Figure 3-1	Example F1 Reject: Visible Scratch	2	Figure 3-31	Example FRA6 Reject: Maximum Gap Is >0.5 mm	17
Figure 3-2	Example F2 Reject: Visible Scratches on the Front Side of Frame.	3	Figure 3-32	Example FRA6 Reject: Sharp Edge Is Removed and the Frame Has Been Scratched.	17
Figure 3-3	Example F2 Reject: Scratch on the Front Side of Frame.	3	Figure 3-33	Example FRA7 Reject: The Protruding Part of the Tape Must Be Removed	18
Figure 3-4	Example F5 Acceptable: (Backside/Rear – Internal)	4	Figure 3-34	Example JBA1 Acceptable: Maximum of 10 mm Misalignment (Illustration)	19
Figure 3-5	Example F5 Reject: Non-Uniform Color. Uneven Anodizing.	5	Figure 3-35	Example JBA1 Reject: >10 mm Misalignment (Illustration)	20
Figure 3-6	Example F5 Reject: Surface Blemish.	5	Figure 3-36	Examples JBA2 Junction Box Manufacturer Recommended Configurations	21
Figure 3-7	Example F5 Reject: Blemish on Frame.	5	Figure 3-37	Example JBA3 Target	22
Figure 3-8	Example FRA1 Target	7	Figure 3-38	Example JBA3 Acceptable	22
Figure 3-9	Example FRA1 Acceptable: Good Crimp	7	Figure 3-39	Example JBA3 Reject: Junction Box. Adhesive collar issue with missing junction box sealant.	22
Figure 3-10	Example FRA1 Reject: Frame Assembly – Alignment Gap Too Large	8	Figure 3-40	Example JBA3 Reject: Insufficient Sealant Around Junction Box and Uneven Sealing Plane for Junction Box	23
Figure 3-11	Example FRA1 Reject: Frame Assembly – Alignment Gap Too Large	8	Figure 3-41	Example Drawing/Illustration of Sealant at the Junction Box	23
Figure 3-12	Example FRA1 Reject: >0.7 mm Offset	8	Figure 3-42	Junction Box Without Adhesive Collar on the Fourth Side of the Junction Box per Junction Box Supplier Instructions (Top View)	23
Figure 3-13	Example FRA2 Target	9	Figure 3-43	Junction Box Without Adhesive Collar on the Fourth Side of the Junction Box per Junction Box Supplier Instructions (Side View)	23
Figure 3-14	Example FRA2 Acceptable	9	Figure 3-44	Example JBA4 Acceptable: Example Amount of Sealant Around Junction Box	24
Figure 3-15	Example FRA2 Reject: Sealant Inconsistent and over Frame Top Edge.	10	Figure 3-45	Example JBA5 Target	25
Figure 3-16	Example Reject: Void in Sealant.	10	Figure 3-46	Example JBA5 Acceptable	25
Figure 3-17	Example FRA3 Target	11	Figure 3-47	Example JBA5 Rejects	26
Figure 3-18	Example FRA3 Acceptable	11	Figure 3-48	Example JBA6 Target	26
Figure 3-19	Example FRA3 Reject: Sealant Gap	12	Figure 3-49	Example JBA6 Acceptable	27
Figure 3-20	Example FRA3 Reject: Damage in Sealant ..	12	Figure 3-50	Example JBA6 Reject	27
Figure 3-21	Example FRA4 Target	12	Figure 3-51	Example JBA7 Target	28
Figure 3-22	Example FRA4 Acceptable	13	Figure 3-52	Example JBA7 Acceptable	28
Figure 3-23	Example FRA4 Reject	13	Figure 3-53	Example JBA7 Reject	28
Figure 3-24	Example FRA5 Target	14	Figure 3-54	Example JBA8 Target	29
Figure 3-25	Example FRA5 Acceptable	14	Figure 3-55	Example JBA8 Acceptable	29
Figure 3-26	Example FRA5 Rejects	15	Figure 3-56	Example JBA11 Target	31
Figure 3-27	Example FRA6 Target	16	Figure 3-57	Example JBA11 Acceptable	31
Figure 3-28	Example FRA6 Acceptable	16	Figure 3-58	Example JBA11 Reject	31
Figure 3-29	Example FRA6 Acceptable: Maximum Gap is ≤ 0.5 mm	16	Figure 3-59	Example JBA12 Target	32
Figure 3-30	Example FRA6 Reject	17	Figure 3-60	Example JBA12 Acceptable	32
			Figure 3-61	Example JBA12 Reject	33
			Figure 3-62	Example JBA12 Reject	33
			Figure 3-63	Example JBA12 Length/Height and Width of the Solder Mark (Sample 1)	34

Figure 3-64 Example Length/Height and Width of the Solder Mark (Sample 2) 34

Figure 3-65 Example JBA15 Target 36

Figure 3-66 Example JBA15 Acceptable 36

Figure 3-67 Example JBA15 Reject: Damaged Terminal 36

Figure 3-68 Example JBA17 Example Target 37

Figure 3-69 Example JBA17 Example Acceptable 37

Figure 3-70 Example JBA17 Reject: Uneven Sealing Plane for Junction Box 37

Figure 3-71 Example JBA18 Example Reject 38

Figure 3-72 Example JBA19 Reject 38

Figure 3-73 Example MH1 Target 39

Figure 3-74 Example MH1 Acceptable 39

Figure 3-75 Example MH1 Reject: Incorrect Bolt Size 39

Figure 3-76 Example L1 Target 40

Figure 3-77 Example L1 Acceptable 41

Figure 3-78 Example L5 Reject 42

Figure 3-79 Example PFA1 Target 43

Figure 3-80 Example PFA1 Acceptable 43

Figure 3-81 Example PFA1 Reject: Contamination on Glass Surface 43

Figure 3-82 Example PFA3 Reject: Label Smear 44

Figure 3-83 Example PFA6 Rejects 45

Figure 3-84 Example PFA7 Rejects 46

Figure 3-85 Example EL1 Rejects 47

Figure 4-1 Example: Use of Frame Which Puts into Position the Frames to Ensure Frame Squareness 48

Figure 4-2 Example: Lid Closure Label 48

Figure 4-3 Example: Press Used to Guarantee the Planarity of the Junction Box 49

Figure 4-4 Example: Shape Used to Ensure Correct Label Alignment 49

Figure 4-5 Example: Packaging of Solar Modules with Cardboard 50

Figure 4-6 Example: Cardboard Used Between Modules to Avoid Issues During Shipping 51

Figure 4-7 Example: Bar Code Stickers Used on Packaging of Solar Modules 51

Figure 4-8 Example: Protective Film Used Around Stacked Solar Modules 51

Figure 4-9 Example: Good Pallet Height Used During Shipping of Solar Modules 51

Figure 4-10 Example: Broken Module Due to Improper Loading During Shipping 52

Figure 4-11 Example: Improper Module Loading During Shipping 52

Figure 4-12 Example: Improper Module Loading During Shipping 52

Figure 4-13 Example: Broken Chipboard Pallet During Shipping 52

Tables

Table 3-1 Summary of Color and Surface Finish Frame Classifications 6